

CAPTURE COPTER*

JURASSIC PARK


ASSEMBLY




1. Snap pegs on launcher support into holes on both sides of copter bottom.




2. Press landing skids into slots on both sides of copter.




3. Tie cable onto fin. Feed cable under crossbar. Tie cable onto hook.



4. Snap rear rotor blades onto rear wing.



5. Align each rotor blade with pegs on prop and snap down into position.



6. Attach weights to corners of net by inserting one prong through hole in net, then twisting.




7. Snap launcher into copter. Insert missile into launcher. You will hear a click when it is inded. Pull

CAPTURE COPTER[™]

JURASSIC PARK

JURASSIC PARK TM & "UNIVERSAL CITY STUDIOS, INC. AND AMBLIN ENTERTAINMENT, INC. ALL RIGHTS RESERVED LICENSED BY MCA UNIVERSAL MERCHANDISING, INC.




8. Apply labels to assembled pieces using numbers on label sheet and these illustrations as a guide.




9. Propellers spin manually.



10. Figure can sit inside cockpit.





11. Squeeze two levers together under Dino net launcher until cocked. You will hear a click when it is loaded. Insert each weight into corner slots.



12. Press button on top to drop net.





13. Attach hook to four corners of net. Slide fin to raise and lower net.

9Kenner